

HAND MODE	Hour hand	Minute hand	24-hour hand	Dual time hand (24 hour)	Center hand		Stopwatch 1/10 sec. hand
					Stopwatch second	Date indicator	
TIME	Current time			Dual time (24-hour)	N/F	Date	N/F
	Hour	Minute	24-hour				
TIME	Current time			Dual time (24-hour)	N/F	Date	N/F
	Hour	Minute	24-hour				
SET	Alarm time			*1	N/F	Date	N/F
	Hour	Minute	24-hour				
→∅←	"0" position (12 o'clock position)			N/F	"0" position	N/F	"0" position
TIMER	N/F	Timer minute	N/F	N/F	Timer second	N/F	*2
CHRONO.	Stopwatch			N/F	Stopwatch second	N/F	Stopwatch 1/10 sec.
	Hour	Minute	Hour				

HAND MODE	Crown position							
	Normal			First click			Second click	
	Crown	Button		Crown	Button		Button	
		"A"	"B"		"A"	"B"	"A"	"B"
TIME	Mode change	N/F	N/F	Dual time setting	Calendar setting		Time setting	
TIME	Mode change	Alarm test by pressing "A" and "B" simultaneously.		Dual time setting	Calendar setting		Time setting	
SET	Mode change	N/F	N/F	*	N/F	N/F	Alarm setting	
→∅←	Mode change	N/F	N/F	*	Adjusting stopwatch 1/10 sec. and stopwatch sec. hands.		Adjusting hour, minute and 24-hour hands.	
TIMER	Mode change		Recall of preset time	*	N/F	N/F	Timer setting	
		Start Stop	Reset					
CHRONO.	Mode change	Start Stop	Split Reset	*	N/F	N/F	N/F	N/F